

A11 (001)	Lead TB 1	A56 (038)	Enorjizor	B23 (075)	Ana Punch	B68 (112)	NU-NRG Bass
A12 (002)	Dist TB 1	A57 (039)	JP8 Sprang	B24 (076)	Atom Brain	B71 (113)	TalkBox Bass
A13 (003)	Dist Sqr TB	A58 (040)	PortaSynLead	B25 (077)	Foiled MC	B72 (114)	Incontinence
A14 (004)	Dist TB 2	A61 (041)	Wah Lead	B26 (078)	101 Bass 1	B73 (115)	Bari Voice
A15 (005)	Dist TB 3	A62 (042)	Beep Mod	B27 (079)	House Bass	B74 (116)	Ac.Bass
A16 (006)	TB + Voco	A63 (043)	Dist Lead 1	B28 (080)	101 Bass 2	B75 (117)	E.Ac.Bass
A17 (007)	Dist TB 4	A64 (044)	Freaky Fry	B31 (081)	202 Bass	B76 (118)	Acid Jazz Bs
A18 (008)	Lead TB 2	A65 (045)	JU2 SubOsc 1	B32 (082)	Psycho Funk	B77 (119)	Soup?s Bass
A21 (009)	Devil TB	A66 (046)	JU2 SubOsc 2	B33 (083)	Talking Line	B78 (120)	Fingered Bs
A22 (010)	Dual TB	A67 (047)	Froggy	B34 (084)	Inside Bass	B81 (121)	FingBsVeloSw
A23 (011)	HiLo303ModSw	A68 (048)	Synth Lead 2	B35 (085)	Bubble Bass	B82 (122)	PickedBass 1
A24 (012)	Arpness TB	A71 (049)	Singin? MINI	B36 (086)	Bass Bleep	B83 (123)	PickedBass 2
A25 (013)	Acid Line	A72 (050)	Plastic Tone	B37 (087)	Wiggle Bass	B84 (124)	Fretless Bs
A26 (014)	Dist TB 5	A73 (051)	SinusoidRave	B38 (088)	Twist Bass	B85 (125)	Phot Bass
A27 (015)	Lead TB 3	A74 (052)	Sine Me Up	B41 (089)	Octa Bass	B86 (126)	Slap Bass
A28 (016)	Lead TB 4	A75 (053)	Spooky Sine	B42 (090)	BT?s Sticky	B87 (127)	R&B B-Slides
A31 (017)	TB Tra Bass	A76 (054)	Sine Tone	B43 (091)	MG Bass	B88 (128)	Syn Stack 1
A32 (018)	Acid TB	A77 (055)	D50 Saw Lead	B44 (092)	FM Super Bs	C11 (001)	Strong Brass
A33 (019)	Psyche-TB	A78 (056)	Dst Syn Lead	B45 (093)	Solid Bass	C12 (002)	You Can Fly
A34 (020)	TB + Sine	A81 (057)	Big Up Massv	B46 (094)	T Nite Bass	C13 (003)	Syn stack 2
A35 (021)	Hi-Pass TB	A82 (058)	Warm SawLead	B47 (095)	Front 505	C14 (004)	Dawn Of Man
A36 (022)	Moog Saw	A83 (059)	Hartnoll Era	B48 (096)	Def Bass 1	C15 (005)	Saw Stack 1
A37 (023)	OB Saw	A84 (060)	Skegness 97	B51 (097)	Def Bass 2	C16 (006)	Saw Stack 2
A38 (024)	MG Lead	A85 (061)	Simply June	B52 (098)	Sine Bass 1	C17 (007)	DLM Stack
A41 (025)	Poly Key	A86 (062)	The Brothers	B53 (099)	Sine Bass 2	C18 (008)	DOC Stack
A42 (026)	Synth Pulse	A87 (063)	Dist Lead 2	B54 (100)	RollModRezBs	C21 (009)	LN2 Stack
A43 (027)	Dual Profs	A88 (064)	Dark SawLead	B55 (101)	Gate Me Buzz	C22 (010)	Bend Stack
A44 (028)	Axe of 80	B11 (065)	Dist Lead 3	B56 (102)	System Bass	C23 (011)	Freedom
A45 (029)	MG Square	B12 (066)	Mosquito	B57 (103)	Spike Bass	C24 (012)	Good Bean
A46 (030)	Square Lead1	B13 (067)	Phazyn Vox	B58 (104)	Solid Goa	C25 (013)	JP8000 5th
A47 (031)	Square Lead2	B14 (068)	Voc Saw	B61 (105)	Rezo Bass	C26 (014)	Mega 5th
A48 (032)	Square Lead3	B15 (069)	VT Vox	B62 (106)	Blip Bass	C27 (015)	5th Saw
A51 (033)	Lucky	B16 (070)	Pure Voice	B63 (107)	Pizz Bass	C28 (016)	4th Saw
A52 (034)	Synth Lead 1	B17 (071)	Robo Vox	B64 (108)	Voco Bass	C31 (017)	Soundtrack
A53 (035)	Moon Lead	B18 (072)	Hallucinate	B65 (109)	VoCoRoBo	C32 (018)	Rise Pad
A54 (036)	Rezo SynLead	B21 (073)	Seq.Synth	B66 (110)	Dust Bass	C33 (019)	Warm Pad
A55 (037)	Wspy Synth	B22 (074)	Analog Seq	B67 (111)	ArtCore Bass	C34 (020)	JP + OB Pad

C35 (021)	Planet	C83 (059)	OB Slow Str	D51 (097)	Trek Storm	E17 (007)	Rezo Noise
C36 (022)	Additive	C84 (060)	Syn.Strings1	D52 (098)	Abduction	E18 (008)	Vinyl Noise
C37 (023)	Noise Pad	C85 (061)	Syn.Strings2	D53 (099)	1st Contact	E21 (009)	Tornado Jet
C38 (024)	Sweep Pad 1	C86 (062)	OB Strings	D54 (100)	Ice Cave	E22 (010)	Smooth Jet
C41 (025)	Sweep Pad 2	C87 (063)	Rhap Strings	D55 (101)	Rev Cord	E23 (011)	Sweep Noise
C42 (026)	Alles Padde	C88 (064)	Banded Jupe	D56 (102)	Blue Random	E24 (012)	ModWhtSweep
C43 (027)	Sky Light	D11 (065)	NU-NRG Str	D57 (103)	Sync Tone	E25 (013)	Perk Breath
C44 (028)	Stargate MC	D12 (066)	Violin	D58 (104)	Seq Up	E26 (014)	Pink Bomb
C45 (029)	Middle Grow	D13 (067)	Contrabass	D61 (105)	SawLFOSaw	E27 (015)	64voicePiano
C46 (030)	AiRye Bread	D14 (068)	Tremolo Str	D62 (106)	Calculating	E28 (016)	Ac.Piano 1
C47 (031)	NU-NRG Org	D15 (069)	Pizzicato 1	D63 (107)	Touch EF	E31 (017)	Ac.Piano 2
C48 (032)	Halo Pad	D16 (070)	Pizzicato 2	D64 (108)	Welding	E32 (018)	Epic House
C51 (033)	Str/Brs Pad	D17 (071)	Pizz It	D65 (109)	Press Machin	E33 (019)	Hush Piano
C52 (034)	Syn Brs Pad	D18 (072)	Guardians	D66 (110)	EF Tribe	E34 (020)	Happy Piano
C53 (035)	Simple Pad	D21 (073)	Gat Passion	D67 (111)	Scratch Alt	E35 (021)	BPF Piano
C54 (036)	OB Rezo Pad	D22 (074)	Syn Harp	D68 (112)	Analog FX	E36 (022)	Honky-tonk
C55 (037)	Sweet Vocode	D23 (075)	Voice Oohs	D71 (113)	Non TB	E37 (023)	NY Piano+Str
C56 (038)	Thin Pad	D24 (076)	Solo Vox	D72 (114)	Nasty Filt	E38 (024)	Voice Piano
C57 (039)	Attack Pad	D25 (077)	Syn Vox	D73 (115)	Psy-Ence	E41 (025)	Old E.Piano
C58 (040)	Metal Pad	D26 (078)	Choir Aahs	D74 (116)	Music Hi	E42 (026)	E.Piano 1
C61 (041)	Atmosphere	D27 (079)	Space Voice	D75 (117)	Uber Zone	E43 (027)	E.Piano 2
C62 (042)	Fantasia	D28 (080)	Star Voice	D76 (118)	Down Gown	E44 (028)	Cool Rhodes
C63 (043)	Feedbackwave	D31 (081)	Brightness	D77 (119)	For Giving	E45 (029)	Psycho EP
C64 (044)	Pacifica	D32 (082)	Vox Lead	D78 (120)	Sound Alarm	E46 (030)	Trip E.Piano
C65 (045)	Atmosphere 2	D33 (083)	Auhbient	D81 (121)	Acid Drone	E47 (031)	Rotary Rhode
C66 (046)	Sub Atmosphe	D34 (084)	Auh Luv Rave	D82 (122)	X-Mod	E48 (032)	EP-Organ
C67 (047)	Machine Pad	D35 (085)	PCM Life	D83 (123)	X-FM/Org	E51 (033)	Harpsichord
C68 (048)	Detuned Pad	D36 (086)	Noisevox	D84 (124)	X-FM Bass	E52 (034)	Clavi
C71 (049)	Scoop Pad	D37 (087)	Trance Voice	D85 (125)	Hard BD?	E53 (035)	Digi Clavi
C72 (050)	Psycho Trevo	D38 (088)	Effect Acer	D86 (126)	S&H Voc	E54 (036)	FM Clavi
C73 (051)	Floating Pad	D41 (089)	Alternative	D87 (127)	X-TlkBxBass	E55 (037)	AnalogClavi1
C74 (052)	Fancy Pad	D42 (090)	Hard Pure	D88 (128)	X-Kick/TB	E56 (038)	AnalogClavi2
C75 (053)	Strings 1	D43 (091)	Metal EF	E11 (001)	X-Org/Nz	E57 (039)	Funky Clavi
C76 (054)	Strings 2	D44 (092)	Dly Tone	E12 (002)	X-Pizz/Rng	E58 (040)	RotaryOrg Sl
C77 (055)	Old StringSW	D45 (093)	Osci Frog	E13 (003)	White Noise	E61 (041)	RotaryOrg Fs
C78 (056)	Swim Strings	D46 (094)	Cal + After	E14 (004)	Pink Noise	E62 (042)	Gospel Spin
C81 (057)	Eclip-Str	D47 (095)	8b Pad	E15 (005)	P5 Noise	E63 (043)	L Org F
C82 (058)	Slow Strings	D48 (096)	SpaceHighway	E16 (006)	Toy Noise	E64 (044)	Organ 1

E65 (045)	Lp-Hp Organ	F33 (083)	Lo-Fi Gtr	F81 (121)	Pan Flute	G47 (031)	Headz Direkt
E66 (046)	Organ 2	F34 (084)	Terror Dome	F82 (122)	Bottle Blow	G48 (032)	ShoppingCart
E67 (047)	Percsv Organ	F35 (085)	Psycho-G	F83 (123)	Funky Pipe	G51 (033)	Noisy Drill
E68 (048)	Ballad B	F36 (086)	Dist Gtr Chd	F84 (124)	Breath Noise	G52 (034)	Thump Bounce
E71 (049)	FM Club Org	F37 (087)	Going Bald	F85 (125)	Shakuhachi	G53 (035)	Tape Rewind
E72 (050)	Pop Organ	F38 (088)	Gt.Harmonic1	F86 (126)	Sitar 1	G54 (036)	Stop
E73 (051)	Cheese Organ	F41 (089)	Gt.Harmonic2	F87 (127)	Sitar 2	G55 (037)	Ao!
E74 (052)	Reed Organ	F42 (090)	Shafted Gtr	F88 (128)	Santur	G56 (038)	Ha!
E75 (053)	Telstar	F43 (091)	WahGT 2 Menu	G11 (001)	Kalimba	G57 (039)	Seashore
E76 (054)	Church Org	F44 (092)	Gtr Up	G12 (002)	Bagpipes	G58 (040)	Bird
E77 (055)	Organ Bass	F45 (093)	Gtr Down	G13 (003)	PnoBendM7-m7	G61 (041)	Telephone
E78 (056)	Strict Organ	F46 (094)	Gtr Sweep	G14 (004)	Org Chd m7	G62 (042)	Helicopter
E81 (057)	SmkyChrd Org	F47 (095)	Orch Gtr	G15 (005)	BalapChd 9th	G63 (043)	Applause
E82 (058)	Sweep Organ	F48 (096)	Brass	G16 (006)	Wah Gtr Hit	G64 (044)	Gun Shot
E83 (059)	Accordion	F51 (097)	Bright Brass	G17 (007)	Orch Hit 1	G65 (045)	Machine Gun
E84 (060)	Vibraphone	F52 (098)	Hush Brass	G18 (008)	Orch Hit 2	G66 (046)	Laser Gun
E85 (061)	FM Marimba	F53 (099)	Synth Brass1	G21 (009)	Rave-X-Tasy	G67 (047)	Sci-Fi Laser
E86 (062)	Marimba	F54 (100)	Synth Brass2	G22 (010)	Philly Hit 1	G68 (048)	Breath
E87 (063)	Xylophone	F55 (101)	Synth Brass3	G23 (011)	Philly Hit 2	G71 (049)	Rain
E88 (064)	Balaphone	F56 (102)	Syn Brs Lead	G24 (012)	Attack Hit	G72 (050)	Siren
F11 (065)	Timpani	F57 (103)	Obilator	G25 (013)	Funky Hit	G73 (051)	TR909 Tom
F12 (066)	Steel Drum	F58 (104)	OpenUp Brass	G26 (014)	Tekno ChdHit	G74 (052)	TR808 Tom
F13 (067)	Digi Bell	F61 (105)	Brass Fall	G27 (015)	Dist Hit	G75 (053)	Syn Tom 1
F14 (068)	Acid Perc	F62 (106)	Trumpet	G28 (016)	Glasgow Hit	G76 (054)	Syn Tom 2
F15 (069)	MetaL-SD	F63 (107)	MutedTrumpet	G31 (017)	Happy Hit	G77 (055)	Old Syn Tom
F16 (070)	Classy Pulse	F64 (108)	Soprano Sax	G32 (018)	Scene Hit 1	G78 (056)	Taiko
F17 (071)	Glockenspiel	F65 (109)	Alto Sax	G33 (019)	Scene Hit 2	G81 (057)	Slow Down
F18 (072)	Fanta Bell	F66 (110)	Baritone Sax	G34 (020)	Drill Hit	G82 (058)	Boom Drop
F21 (073)	Crystal	F67 (111)	SlideBiteSax	G35 (021)	Gaia Message	G83 (059)	B-Tom-D
F22 (074)	Tubular-Bell	F68 (112)	Sax & Tp	G36 (022)	Rezo Perc	G84 (060)	Mr.Bong Bass
F23 (075)	Shank Bells	F71 (113)	Tuba	G37 (023)	Syn Perc	G85 (061)	Friends of 0
F24 (076)	MKS-30 Melts	F72 (114)	Syn F.Horn	G38 (024)	MG Blip	G86 (062)	Latin Perc
F25 (077)	Trip Lead	F73 (115)	Oboe	G41 (025)	Rev Blip	G87 (063)	Bongo Fury
F26 (078)	Steel-Str.Gt	F74 (116)	Whistle	G42 (026)	Air Blip	G88 (064)	High Timbale
F27 (079)	Clean Gtr	F75 (117)	Ocarina	G43 (027)	Radical Perc	H11 (065)	MutePandeiro
F28 (080)	Jazz Gtr 1	F76 (118)	Recorder	G44 (028)	Machine	H12 (066)	Open Surdo
F31 (081)	Jazz Gtr 2	F77 (119)	Jazz SynLead	G45 (029)	Metal Hit	H13 (067)	Brazil Perc
F32 (082)	Muted Gtr	F78 (120)	Solo Flute	G46 (030)	Tanz Devil	H14 (068)	Tablabaya

H15 (069)	Mute Cuica	H63 (107)	Percus1 Menu	I31 (017)	Harpsichord2	I77 (055)	IndianUnison
H16 (070)	Long Whistle	H64 (108)	Percus2 Menu	I32 (018)	Harpsi 8&4	I78 (056)	Steel Stack
H17 (071)	Agogo	H65 (109)	Cowbell Menu	I33 (019)	Clavi 2	I81 (057)	St.Strings 1
H18 (072)	Short Tamb	H66 (110)	Shaker+ Menu	I34 (020)	Clavi 3	I82 (058)	St.Strings 2
H21 (073)	808 Cowbell	H67 (111)	Rim Menu	I35 (021)	E.Organ 1	I83 (059)	Mono Strings
H22 (074)	CR78 Cowbell	H68 (112)	Cymbal Menu	I36 (022)	E.Organ 2	I84 (060)	MarcatoStr 1
H23 (075)	CR78 Beat	H71 (113)	CHH 1 Menu	I37 (023)	E.Organ 3	I85 (061)	MarcatoStr 2
H24 (076)	Wind-Chime	H72 (114)	CHH 2 Menu	I38 (024)	E.Organ 4	I86 (062)	St.Slow Str
H25 (077)	Rim Shot	H73 (115)	PHH Menu	I41 (025)	E.Organ 5	I87 (063)	Oct. Strings
H26 (078)	TR909 Rim	H74 (116)	OHH 1 Menu	I42 (026)	Positive Org	I88 (064)	Film Octaves
H27 (079)	Hyoshigi	H75 (117)	OHH 2 Menu	I43 (027)	Pipe Organ	J11 (065)	LoFi Strings
H28 (080)	TR626 Shaker	H76 (118)	Clap 1 Menu	I44 (028)	F.Accordion1	J12 (066)	Strings&Chor
H31 (081)	727 Quijada	H77 (119)	Clap 2 Menu	I45 (029)	F.Accordion2	J13 (067)	Hybrid Str 1
H32 (082)	Real CH	H78 (120)	Snare 1 Menu	I46 (030)	Bandoneon	J14 (068)	Hybrid Str 2
H33 (083)	TR909 OH	H81 (121)	Snare 2 Menu	I47 (031)	Harmonica	J15 (069)	Str Stack
H34 (084)	Syn OH	H82 (122)	Snare 3 Menu	I48 (032)	Bright Harmo	J16 (070)	Chambers 1
H35 (085)	TR909 Crash	H83 (123)	Snare 4 Menu	I51 (033)	Nylon Gtr 1	J17 (071)	Chambers 2
H36 (086)	Reverse Cym	H84 (124)	Snare 5 Menu	I52 (034)	Nylon Gtr 2	J18 (072)	Str+Cello 1
H37 (087)	Asian Gong	H85 (125)	Snare 6 Menu	I53 (035)	NylonGtr /SW	J21 (073)	Str+Cello 2
H38 (088)	TR808 Clap	H86 (126)	Kick 1 Menu	I54 (036)	NylnGtr&Str1	J22 (074)	Violin 2
H41 (089)	Down Clap	H87 (127)	Kick 2 Menu	I55 (037)	NylnGtr&Str2	J23 (075)	Violin 3
H42 (090)	Clap Tail	H88 (128)	Kick 3 Menu	I56 (038)	6Gtr Harm	J24 (076)	Viola
H43 (091)	Rap&Real Clp	I11 (001)	Ac.Piano 3	I57 (039)	Mute/Pop Gtr	J25 (077)	Cello
H44 (092)	Maddening	I12 (002)	Ac.Piano 4	I58 (040)	Mute Guitar	J26 (078)	Contrabass 2
H45 (093)	TR909 Snare	I13 (003)	St.Ac.Piano	I61 (041)	Pop Guitar	J27 (079)	BrassSect. 1
H46 (094)	TR808 Snare	I14 (004)	Bright Piano	I62 (042)	Far Dist Gtr	J28 (080)	BrassSect. 2
H47 (095)	House Snare	I15 (005)	Metal Piano	I63 (043)	Gtr Fret Nz	J31 (081)	4 Trumpets
H48 (096)	Jungle Snr 1	I16 (006)	Ac.Pno & Str	I64 (044)	Guitar FX	J32 (082)	Sax Sect.
H51 (097)	Jungle Snr 2	I17 (007)	PianoStack 1	I65 (045)	Harp 1	J33 (083)	Soft Brass
H52 (098)	TR808 Kick	I18 (008)	PianoStack 2	I66 (046)	Harp 2	J34 (084)	D50 Brass
H53 (099)	Plastic BD	I21 (009)	Rhodes	I67 (047)	Harp Pad	J35 (085)	Hybrid Brass
H54 (100)	Gate Kick	I22 (010)	Hard Rhodes	I68 (048)	Koto	J36 (086)	Hybrid Bone
H55 (101)	Jungle Kick	I23 (011)	Tremolo EP	I71 (049)	Shamisen	J37 (087)	Rugby Horn
H56 (102)	Scrтч/Vo Mn	I24 (012)	Sine Rhodes	I72 (050)	Sitar/Drone	J38 (088)	Speed Trom
H57 (103)	Flexi Vox Mn	I25 (013)	MIDI E.Piano	I73 (051)	Sitar 3	J41 (089)	Tp & Tb
H58 (104)	Hit Menu	I26 (014)	Cellesta	I74 (052)	Sitar Drone	J42 (090)	Trumpet 2
H61 (105)	Indust Menu	I27 (015)	Key Stack	I75 (053)	Santur 2	J43 (091)	Trumpet SW
H62 (106)	Tom Menu	I28 (016)	Tria Bells	I76 (054)	Harp&Santur	J44 (092)	Strong Tp

J45 (093)	Trombone	J56 (102)	Clarinet	J67 (111)	Soundtrk 305	J78 (120)	SF Alert
J46 (094)	Tuba 2	J57 (103)	Oboe & Cla	J68 (112)	PianoFX Pad	J81 (121)	Noise Hit
J47 (095)	F.Horn	J58 (104)	Oboe&Cla&Flt	J71 (113)	RND Str Pad	J82 (122)	Chord Hit
J48 (096)	Horn Lead	J61 (105)	7th Flute Ld	J72 (114)	HiPass Str	J83 (123)	Timpani 2
J51 (097)	Horn Pad 1	J62 (106)	X Pipe	J73 (115)	Sweeping Str	J84 (124)	Taiko Menu
J52 (098)	Horn Pad 2	J63 (107)	Digi Pad 1	J74 (116)	Sweep Saws	J85 (125)	Dolak Menu
J53 (099)	T.Sax SW	J64 (108)	Rhodes Pad	J75 (117)	Strobe 305	J86 (126)	Tabla Menu
J54 (100)	Oboe 2	J65 (109)	Digi Pad 2	J76 (118)	Babble	J87 (127)	China Menu
J55 (101)	Oboe & Flt	J66 (110)	5th Pad 305	J77 (119)	Sweeping	J88 (128)	Drum Menu

### Bank Select table

Patch	CC#0	CC#32
Preset A&B	81	0
Preset C&D	81	1
Preset E&F	81	2
Preset G&H	81	3
Preset I&J	82	0
User A&B	85	0
User C&D	85	1
Card A&B	86	0
Card C&D	86	1
Card E&F	86	2
Card G&H	86	3

Rhythm Set	CC#0	CC#32
Preset A 81	0	
Preset B 82	0	
User A	85	0
Card A	86	0